

Helpful information

Find out more about 3's services

- Visit **three.co.uk**
- For more information on My3 visit **three.co.uk/my3**
- Email **customer.services@3mail.com** or call customer services on **333** (free) from your 3 phone or **0843 373 3333** from a landline (calls charged at 5p per minute).

Published by Hutchison 3G UK Limited, trading as 3. All rights in this publication are reserved and no part may be reproduced without the prior written permission of the publisher.

© 2009 Hutchison 3G UK Limited. A Hutchison Whampoa company Hutchison 3G UK Limited trading as 3 is a service provider. ZTE is the manufacturer of the 3 Skypephone S2x phone. ZTE has provided the information on its features set out in this user guide.

The contents are believed to be correct at the time of going to press, but any information, products or services mentioned may be modified, supplemented or withdrawn. The provision of any products and services by Hutchison 3G UK Limited is subject to 3's customer terms (available at **three.co.uk**). The customer terms will take precedence if there is any discrepancy with this publication.

'3' and related images, logos and names referred to in this publication are trademarks of the Hutchison Whampoa group of companies.

Skype, and its associated trademarks and logos and the  symbol are trademarks of Skype Limited.

DD0967801 Nov09

	3 Phone	Other phones
3 customer services	333	0843 373 3333
Mail (voicemail, email and faxmail)	123	07782 333 123
Pay As You Go top-up	444	0843 373 4444
Directory enquiries	118 333	118 333
International directory enquiries	118 313	118 313
Disabled and elderly enquiries	195	
Emergency calls	999	999



(124mm)

<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

3 Skypephone S2x

User guide





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Sync your Bluetooth

Connect with a Bluetooth headset

- Press .
- Scroll to select **Settings > Connectivity > Bluetooth > Bluetooth manager**.
- Press  (left or right) to turn on Bluetooth.
- Scroll to select **Visibility on / off** and press  (left or right) to select **On**.
- Press .
- Press **My devices > Search or Search device**.
- Scroll to the device you want to connect with, and press .
- Enter the pass code when you're asked for permission to connect to the device.

Transfer files from your phone via Bluetooth

- Select the file you want to transfer.
- Press **Options > Send > Via Bluetooth**.
- Select the device from **My devices** list to transfer the file.

If there is no device in **My device** list, press **Search** to search all available Bluetooth devices.

Using your phone as a modem

You can connect your phone to your PC using the USB data cable in the box or a Bluetooth adapter. You can then use your phone as a Modem, but you'll first need to use the CD Rom provided to install the PC suite and drivers.



Getting started	5
Getting to know your phone	9
Choosing settings on your phone	19
Setting up Skype™	25
Getting onto the internet and Planet 3	29
Calls, texts, emails and contacts	33
Music, pictures, video and games	45
Connecting to Bluetooth	49



<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Getting started





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>




Before you do anything

To get started you need to insert your SIM, battery and charge your phone.

- 1 Remove battery cover
- 2 Insert your SIM
- 3 Insert your battery, replace battery cover and fully charge the battery before using it for the first time.


1



2



3





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Getting to know your phone





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



The buttons on your phone

This section explains what all the icons and symbols mean.



- 1 Soft keys (left and right)**
Press to choose the option that appears on the bottom left / right of the screen
- 2 Send key**
Make or answer calls
View call log
- 3 Menu key**
Takes you to the Main Menu
- 4 Scroll key**
Navigate, left, right up or down
Move between icons in Switcher
- 5 OK key**
Press to select or confirm options
- 6 Clear character**
Press to clear character(s)
- 7 On / off and End key**
Turn phone on / off
End a call / reject an incoming call
To cancel calling
Go back to Start screen



1 Volume (up and down)

2 Camera

3 Switcher key

Easy access to the Mobile Internet and popular functions like Messages or Contacts

4 Camera key

5 USB connector, headset and charger socket

What you see on your screen

Your screen is divided into four basic screens:
the Status bar, the Main Screen, the Switcher and The Prompt box



1 Status bar

Shows what operations are taking place, Skype status (see page 27) and the battery and signal strength. See the next page for status icon details.

2 Main screen

If you're not on the Start Screen, the screen will show the main menu or the submenu related to that particular feature.

3 Switcher

This area displays the carousel of icons which, gives you quick access to popular applications (see page 16).

4 The Prompt box

Displays instructions and directions that you need to choose using the relevant left / right soft key.

What the status bar icons mean



...you're in a 3G network area.



...you're in a 2G network area.



...your signal strength.



...you've got text messages.



...you've got multimedia messages.



...you've got emails.



...your text Inbox is full.



...your SIM card Inbox is full.



...you've got missed calls.



...you've got missed video calls.



...you've set your alarm clock.



...Skype is active.



...how much battery life you've got.



...your battery is low.



...Bluetooth is on.



...you've got earphones plugged in.



...your earphone & vibrate mode is on.



...your multimedia message Inbox is full.



...your email Inbox is full.



...transferring files.



...your call divert is on.



...you're on vibration mode.



...your ringtone is turned off.



...you've got meeting mode on.



...you're roaming networks.



...can't detect a network.
You can only make emergency calls.

Signal strength

The signal strength icon shows on the top left corner of the screen. More bars indicate a stronger signal. For example,  indicates a strong signal.

Switcher

The Switcher shows your most important applications and anything you've got open at the time. It's a carousel of icons at the bottom of the screen, that shows up to twenty icons. Whatever function you're using, you can access the Switcher instantly by pressing the Switcher key on the side of your phone. And when the phone is idle the Switcher carousel shows.

You can choose to add or take away icons from the carousel, so if you've got a favourite website or application you can get to it straight away.

When you're using an application and you call up the Switcher, the home icon appears in the centre. If the phone is idle, the home icon doesn't appear (since you're already there).

- To add an item to the Switcher, select **Options > Add items to switcher.**
- To remove item from the Switcher, select **Options > Remove from switcher.**

- To access an open application, use left or right key to select the application and then press **■**.
- To close a current application select **Options > Close.**
- To see the help about Switcher select **Options > About Switcher.**



Switcher



Shortcuts on your phone

Favourites is where you can shortcut to internet sites e.g. Facebook, BBC, You Tube, Windows Live™ Messenger. To get to **Favourites**, press  (left)

Press left to access messages (new message, inbox, sent and more)

Press to open **Skype**

Press down to access voicemail



Planet 3 is where you'll find music and games, and **My3**, as well as links to favourite internet sites

Press up to see all your calls including missed calls

Press right to use the camera, media player and other multimedia settings

Press down to bring up your contacts



<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Choosing settings on your phone



The menu options

When you click on  a number of different options appear. Here's what you'll find in each one.



Alarm



Browser

Google search
Enter address
Bookmark
History
Saved page
Planet 3
Settings



Camera



Calls



Contacts

Handset
SIM



File manager

Photos
Audios
Videos
Memory card
Others



Games & apps

Install Application
Java Certificates
Skype
MShop
Messenger
Games
Grease 4 free
Yell
Bejeweled
The Sims 3
Brain Genius 2
Millionaire 4th Edition
Premierscores0



Multimedia

Camera
Media player
Voice recorder
Playlist
Streaming URL



Messages

New message
Inbox
Skype chats
Outbox
Drafts
Sent
Settings
Memory info

New email
IMAP4 mailbox
Outbox
Drafts

Sent
Settings
Memory info



Settings

Profiles
Handset
Screen
Connectivity
Calls
Security



Skype™



Tools

Calendar
Calculator
World time
Stopwatch
Currency convert

Changing the settings on your phone

Power on / off

- Press and hold  to switch your phone on and off.

Set the phone language

- Press **Menu > Settings > Phone > Language**
- Press  (up or down) to select a language from the list.
- Press  to select.

Set the time and date

You can select to turn on Network time by pressing **Menu > Settings > Phone > Network time**. If you want to set the time and date by yourself, you'll need to turn off Network time.

- Press **Menu > Settings > Phone > Time & date**.
- Press  (up or down) to select **Time**, **Date**, or **Time format**.

- Enter the time and date, or press  (left or right) to choose a time format.
- Press  to save.

Set the missed call(s) tones

You can set the missed calls tone to notify you if there are missed calls.

- Press **Menu > Settings > Phone > Missed Call(s) Tone**.

Tips: If you select an item, like 5 min, you'll be notified every 5 minutes if there are missed calls. You can also select **Off** to turn off this function.

- Press  (up or down) to select an item from the list.
- Press  to select.



Set wallpaper

- Press  from the Start screen and select **Settings > Screen > Set wallpaper**.
- Use  to select an image from phone.
- When you've chosen your wallpaper, press the .

You can also take a photo using your camera and set it as wallpaper. Take a photo and press **Options > Set as wallpaper**.

Keyboard backlight

- Press **Menu > Settings > Screen > Keyboard backlight**.
- Press  (up or down) to select the **Duration** or **Period**.
- Press  (left or right) to set the duration time or the period time. If you select **Customise** in Period, you may need to set the time period.
- Press  to save.

Set brightness

- Press **Menu > Settings > Screen > Set brightness**.
- Press  (up or down) to adjust the brightness of your display.
- Press  to save.

Set the ringtone

- Press **Menu > Settings > Profiles** and select the profile you are using.
- Press  (left) to edit it.
- Select **Ringtone** and choose an audio file from your phone or memory card.
- Press  to select.

Lock / Unlock keypad

- Press and hold . This will lock the keypad and a  icon will show on the display.
- To unlock the keypad, press and hold .



Personalising your phone

Your phone has pre-set settings which you can change.

- Press **Menu** > **Settings** > **Profiles** and select a profile to personalise it.
- Press  (left) to edit the selected profile.
- Select an item you want to change from the following list:

Ringtone: Select the voice ringtone for incoming voice call notification.

Videocall ringtone: Select the videocall ringtone for incoming video call notification.

Skype call ringtone: Select the ringtone for incoming Skype call notification.

Ring volume: Adjust the ringtone volume level.

Ring type: Select the options for incoming calls.

Message tone: Select the sound options for new messages

Keytones: Select to turn on / off the keypad tone.

Warning tone: Select to turn on / off the warning tone.

Power on / off sound: Select to turn on / off the power on / off melody.

Earpiece volume: Adjust the volume of the earpiece.

- Press  to change the settings.



<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Setting up Skype

With Skype on 3, you can call and instant message the millions of people who use Skype in the UK and worldwide
- free from your mobile in the UK. Plus use Skype to save on calls to phones abroad.



Sign into Skype

If you have a Skype account

- From the Start screen, press  to open Skype.
- Select **Sign in for existing user**, then enter your Skype Name and password.
- Scroll to **Sign me in** and set it as **Automatically** or **Manually**. If you select **Automatically**, you'll automatically sign into Skype each time you turn on your phone.

If you don't have a Skype account, here's how to create one

- From the Start screen, press  to open Skype.
- Scroll to **Create account for new users** and press .

- Read the Skype End User Licence, Terms of Service and Privacy Policy available at www.skype.com/eula, www.skype.com/tos or www.skype.com/privacy. Select **Accept** and enter a Skype Name, password and an email address on the Create account screen.
- Press  to save the settings.

Sign out of Skype

- From the Start screen, press  to open Skype.
- Select **Options > Sign Out**.

Change Skype sign in setting

- From the Start screen, press  to open Skype.
- Select **Options > Settings > Sign me in Automatically / Manually**.

Skype contacts

Add a Skype contact

- From the Start screen, press  to open Skype.
- Select **Options > Add a contact** and then enter the person's Skype Name and select **Save**.

You'll also have the option to save the Skype contact in Contacts.

Import your Skype contacts

You can save your Skype contacts onto your phone along with your other contacts.

- Press  (down) from the Start screen.
- Select **Options > Skype > Get contacts**.

Skype status

Skype status icons

The Skype status icon you select will appear on your mobile's status bar. Your Skype contacts can see it so they'll know whether you are online or not available.

Change Skype status

- From the Start screen, press  to open Skype.
- Select **Options > Change status**.

You can choose to set you own status to:

-  **Online** - others will see you as online (default setting when you sign in)
-  **Away** - others will see you as away
-  **Do Not Disturb** - others will see you as do not disturb
-  **Invisible** - others will see you as offline

Skype chat

Skype chat

- From the Start screen, press  to open Skype.
- Scroll to your preferred Skype contact, then select **Options > Start chat**.
- Write your message and select **Send**.

Skype chat is a network dependent feature.

You can view your Skype chat log by pressing  from the Start screen **Messages > Skype chats**.

Skype calls

Make free Skype-to-Skype calls

- From the Start screen, press  to open Skype.
- Scroll to a contact and press  to call them with Skype.

Call phones abroad with Skype

With a little Skype Credit, you could save on calls to phones abroad. So speaking to far away friends and family needn't cost the earth.

For more details, go to **www.skype.com/go/credit**.

When using Skype on your 3 mobile, you can only call phones outside your country.

Getting on the internet and Planet 3

Our network has been designed and built for the phone internet,
so getting online on your phone comes naturally when you're with 3.



The internet on your phone

There are a couple of ways in which you can find your favourite sites quickly:

- Click on **Favourites**  (left).
- Click on  **Planet 3**  (right).

Planet 3

In **Planet 3** you'll find:

- All the links to the best of the phone internet, plus the latest news stories and the best deals.
- A section called **Services** which is a complete menu of what's in **Planet 3**. You'll see categories that'll help you find exactly what you need.
- **My3** is the best place to keep track of what you're spending. Make sure you keep clicking on it to check your account.

facebooktwitterBBCYouTube

Find out what services you can get in Planet 3



Social networks - you'll find Facebook, Windows Live™ Messenger, myspace, YouTube and more



News & info - news and showbiz, sport & weather from BBC, The Sun and others



Games & puzzles - latest releases to keep you entertained



3MusicStore - over 3 millions tracks as well as videos and realtunes to choose from



Chat & Blog - have your say. You'll find Twitter, Windows Live™ Messenger and more



Entertainment - stay in touch with the latest celebrity gossip and entertainment news



Personalise & Downloads - loads of useful links to Dialtunes, Realtunes and Pix.

And there's loads more. Click on  now.

YAHOO!


Windows Live
Hotmail


Windows Live
Messenger

eBay



<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Calls, texts, emails and contacts





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Make voice and video calls

Make a voice call

To make a call from the Start screen:

- Enter the phone number.
- Press  to make a voice call.

Make a video call

To make a call from the Start screen:

- Enter the phone number.
- Select **Options > Call > Video call** for a video call.
- Press  (right) to cancel the call.
- Press  to end call.

Make a call from Contacts

- Press  (down).
- Scroll to your preferred contact and press  for a voice call.
- Scroll to your preferred contact and select **Options > Call > Video call > OK** for a video call.

Make Skype-to-Skype calls

See page 28 for how to make Skype-to-Skype calls.

Make emergency calls

Enter the appropriate emergency number for your location then press .

Please note: Skype cannot be used to make emergency calls.

Receive calls

- To answer a call press .

Reject calls

- Press .

End a call

- Press .

Call log

- From the Start screen, press .

Make a call from Call log

- Press  from the Start screen and scroll to your preferred contact.
- Press  for a voice call.

Call divert

Lets you transfer incoming voice and video calls to a specified number. For video calls, it must be to another video phone number.

- Press .
- Select **Settings > Calls > Call divert**.
- Scroll to your preferred Call divert option and press .

Call waiting

If there's an incoming call while you are on another call, the phone notifies you with a call waiting tone. It shows the number / name of the waiting call.

- Press .
- Select **Settings > Calls > Call waiting**.
- Press  (up or down) to select to activate or deactivate the function. You can also select **Check status** to check the service status.

Hide your number

This allows you to show or hide your number when making calls.

- Press .
- Select **Settings > Calls > Send my number**.



Call barring

Restrict the calling or receiving of certain calls. To activate or cancel call barring, you have to enter the network password provided by your service provider.

- Press .
- Select **Settings > Calls > Call barring**.
- Press  (up or down) to select an item from the list:

Bar all outgoing calls:

You can't make calls.

Bar outgoing calls (international):

You can't make international calls.

Outgoing international calls except for calls to your home country:

When abroad, you can only make calls to numbers within the current country and to your home country.

Bar all incoming calls:

You can't receive calls.

Bar incoming calls when international roaming:

You can't receive calls abroad when you're roaming on another network.

Cancel all call barring:

Cancel all settings about barring.

Change password:

Change the password.

- Press  (up or down) to select to activate or deactivate the function. You can also select **Check status** to check the service status.



Predictive text and numbers

When writing a message or entering contact details, you can choose predictive text, upper or lower case letters or numbers.

Choosing your writing options

- Press  to open the **Options**.
- Press  (up or down) to choose.

Choose from the following options:

You'll see the following options in the top-right status bar.

-  Predictive text option
-  Uppercase option
-  Lowercase option
-  Number option
-  Symbols and Signs option

Using Predictive text

Predictive text is based on a built-in dictionary and generates words from the combination of letters pressed.

- Press the keys to spell the word you want and as you spell it a list of words will appear.
- To pick the word you want from the list, press  (up or down) and press  to confirm.
- To insert space between words or letters press .
- To delete a letter, put the cursor to the right of it and press . To delete all text press and hold down .

Inserting letters

To get the letter you want, press the relevant ( - ) keys repeatedly until the letter you want appears.

Inserting numbers

Use number keys ( - ) to enter the number. You can only enter the number directly shown on the keypad. The letters can't be entered in this mode.

Inserting symbols

- Press .
- Press  (up, down, left or right) to select a symbol.
- Press  to confirm.

Texts, multimedia and email

You can send and receive texts, pictures, video and voice messages, plus email on your phone.

Text messages

- Press  from the Start screen and select **Messages > New message > Text message**.
- Enter the phone number(s) or press  to select a number from your contacts.
- Scroll to **Message** and write the message.
- Press  to send the message.

Multimedia messages

- Press  from the Start screen and select **Messages > New message > Picture message**.
- Enter the phone number or press  to select a number from your contacts. Scroll to **Message** and enter your message.
- Select **Options > Insert picture / video / sound** and select a file.
- Press  to send the message.

Take a picture or video and send it

- From Start screen press  on the right of your phone.
- Select **Settings > Switch to Video camera / Switch to Camera** to switch between camera and video mode.
- Press  /  to take a picture or press  to start filming and press **Stop** to stop filming.
- Press **Options > Send > Via picture msg / Via Email / Via Bluetooth** to send it.

Set up your Email

- Press  from the Start screen and select **Messages > Email > Settings > Mailbox settings**.
- Select **Options > Edit / Add**.
- At **Mailbox name** enter your name.
- Scroll to **Username** and enter your username.



- Scroll to **Password** and enter your password.
- Scroll to **My email address** and enter the address.
- Scroll to **Display name** and enter the name.
- Scroll to **Outgoing server** and **Outgoing port** and enter the server and port.
- Scroll down for other settings.
- Press .

Send an email message

- Press  from the Start screen and select **Messages > Email > New email**.
- Enter the email address or press  to select an address from your contacts.
- Scroll to **Message** and write your email.
- Press  to send the your email.

Retrieve an email

- Press  from the Start screen and select **Messages > Email > IMAP4 mailbox**.
- Scroll to the email and press .

Reply to an email

- Press  from the Start screen and select **Messages > Email**.
- Scroll to the email and select **Retrieve > View > Options > Reply**.

Browse into mail

- Press  from the Start screen.
- Select  **Services** >  **Mail**.

From the browser you can send, receive, view and manage emails.



Contacts

Add a contact

- Enter a contact number from the Start screen and select **Options > Create new**.
- Enter name and other details and select **Save**.

Edit a contact

- Press  (down) from the Start screen.
- Select **Options > Edit** to edit your contact and then press **Save**.

Delete a contact

- Press  (down) from the Start screen.
- Scroll to the contact your want to delete.
- Select **Options > Delete > Delete contact**.
- Select **Yes** to delete it.

Copy a contact between SIM and phone

- Press  (down) from the Start screen.
- Scroll to the desired contact and select **Options > Copy > Copy to card / Copy to phone**.

Copy contacts between SIM and phone


- Press  (down) from the Start screen.
- Press to select **Phone** or **SIM** tab.
- Select **Options > Copy > Copy all**.

Add a Skype contact

See page 27 for how to add Skype contacts.

Import your Skype contacts

See page 27 for how to import your Skype contacts.





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Music, pictures,
videos and games



Music, pictures, videos and games

Play music


■ Press **Menu** > **Multimedia** > **Media player**.

■ Press **Options** > **Open** > **Files / Playlist** / **Streaming URL** to select the music you want to play.

Files: Switch to the File Manager.

Playlist: Switch to the Playlist.

Streaming URL: Switch to the Streaming URL.





Use the camera

You can hold  from standby mode, press **Menu** > **Camera** or **Menu** > **Multimedia** > **Camera** to activate your camera.

Take photos

- Start the camera.
- Aim the camera lens at the place / object.
- Press  /  to take the photo.

The photo you have taken will be saved in My Pictures folder automatically.

Switch to the video camera

- Start the camera.
- Press **Setting** > **Switch to video camera** to shoot video clips.

Take videos

- Start the camera and then switch to the video camera.
- Press  to start recording.
- Press  to pause recording.
- Press  (left) to stop recording.

View your photos and video clips

- Press **Menu** > **File manager** to access the File manager menu.
- Select **Photos** > **My Pictures** to view the photos, or select **Videos** > **My Videos** to view the video clips.

Access games and apps

- Press .
- Select **Games and apps**.
- Press **Install Application** to go to the default webpage to download applications.





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>



Connecting to Bluetooth





<248mm>

PANTONE Green C: For positional purposes only - Do NOT Print

<124mm>

